



Fripura guidelines for oil life extension:

1. Install Fripura in to the fryer as specified in the instructions.
2. Follow your usual oil management regime, Fripura will not filter the physical particulates out of the oil.
3. Test the oil daily using the Testo meter and take a note of the TPM (total polar material reading).
4. Once the TPM reading on the Testo meter reads 24 then the oil has reached the end of its safe to use life. (The tester will show the reading in red.)
5. Follow your existing procedure to replace the oil and use a new Fripura. After removing the old Fripura from the metal box and throwing away, insert a new Fripura in the box on each oil change.
6. Continue to follow these guidelines every time you change the oil. The key benefits of following these simple procedures are:
 - Reduction in amount of oil used
 - Reduction in calories in food
 - Reduction in harmful acrylamides
 - Reduction in waste
 - Reduction in cleaning
 - Improved food quality